

PCI Extension

[Model PE3R](#)



Slots: 3

Bus: PCI und PCI- 64Bit

Host Interface PC: PCIe, PCI,

Host Interf.Notebook: EC34,
CardBus

 [Data Sheet](#)

PCI Extension

[Model P13 and P13RR](#)



PCI Extension

[Model PE3R-3.3V](#)



Slots: 3

Bus: PCI und PCI- 64Bit 3.3 volts

Host Interface PC: PCIe, PCI,

Host Interf.Notebook: EC34,
CardBus

 [Data Sheet](#)

PCI Extension

[Model P13RR RAS](#)



PCI Extension

[Model P7R and P7RR](#)



Slots: 7

Bus: PCI

Host Interface PC: PCIe, PCI,

Host Interf.Notebook: EC34,
CardBus

 [Data Sheet](#)

Slots: 13

Bus: PCI

Slots: 13

Bus: PCI

Host Interface PC: PCIe, PCI,

**Host Interf.Notebook: EC34,
CardBus**

Host Interface PC: PCIe, PCI,

**Host Interf.Notebook: EC34,
CardBus**



[Data Sheet](#)