

Ethernet TCP / IP transducers / transmitters for temperature, humidity, atmospheric pressure and CO2

[Live Demo of the Web Sensor](#)

Ethernet TCP/IP Temperature, Humidity, CO2 and atmospheric pressure Transducer / Transmitter

Ethernet transducer for:

[Temperature](#)



Transducer for Temperature

Transducer H0530 (int. Sensoren)

Transducer H4531 (ext. Pt1000 Sens.)

Transducer H4531R (ext. Pt1000 Sen.)

Transducer P8510 (interner Sensor)

Transducer P8511 (ext. Sensors)

Ethernet transducer for

[Temperature / Humidity](#)



Transducer for Temperature/humidity

Transducer H3530 (interner Sensor)

Transducer H3531 (ext. Sensoren)

Transducer H3531P (ext. Sensoren)

Transducer H3531R (ext. Sensoren)

Transducer P8511 (ext. Sensor)

Transducer P8541 (ext. Sensors)

Ethernet transducer for:

[Temperature/humidity/pressure](#)



Transducer for Temperature/humidity and atmos. pressure

Transducer H7530 (int. Sensor)

Transducer H7531 (ext. Sensor)

Transducer T7510 (int. Sensor)

Transducer T7511 (ext. Sensor)

Transducer T7610 (int. Sensor)

Transducer T7611 (ext. Sensor)

Transducer P8541 (ext. Sensors)

Transducer P8552 (ext. Sensors)

Transducer T7613 (ext. Sensors)

Transducer P8610 (interner Sensor)

Transducer P8611 (ext. Sensor)

Transducer P8611 (ext. Sensor)

Transducer P8641 (ext. Sensors)

Transducer P8641 (ext. Sensor)

Transducer P8652 (ext. Sensors)

Transducer T0510 (interner Sensor)

Transducer T3510 (int. Sensor)

Transducer T0610 (interner Sensor)

Transducer T3511 (ext. Sensor)

Transducer T4511 (ext. Pt1000
Sen.)

Transducer T3511P (ext. Sensor)

Transducer T4611 (ext. Pt1000
Sen.)

Transducer T3610 (int. Sensor)

Transducer T3611 (ext. Sensor)

[Web Sensor Catalog](#)

[Web Sensor Catalog](#)

[Web Sensor Catalog](#)

Ethernet transducer for

[Air pressure](#)

Ethernet transducer for

[CO2 concentration](#)

Ethernet transducer for

[Temperature, humidity and CO2](#)



Transducer for atmos. Druck



**Transducer for CO2
concentration**



**Transducer for Temperature,
humidity and CO2 concentration**

Transducer T2514 (internal Sensor)

Transducer H5521 (int. Sensor)

Transducer H5524 (ext. Sensor)

Transducer T5540 (int. Sensor)

Transducer T5541 (ext. Sensor)

Transducer H6520 (internal
Sensoren)

Transducer T5545 (int. Sensor)

Transducer T6540 (int. Sensor)

Transducer T6541 (ext. Sensoren)

[Web Sensor Catalog](#)

[Web Sensor Catalog](#)

[Web Sensor Catalog](#)



Opening the Download-Files May require the Adobe-Acrobat-Reader.

[Click here to download the Adobe-Acrobat-Reader.](#)

If you have questions please don't hesitate to contact us any time.

Phone +49 (89) 3133007, **Fax** +49 (89) 3146706, wuntronic@wuntronic.de or send us our [Contact form](#)

Wuntronic GmbH, Heppstrasse 30, D-80995 Munich, Germany